

603/604 Ladies Dress Form **Installation Guide**

Please check the following items in your package. If anything is missing or damaged, please contact your dealer immediately.

6 ITEMS

(1) BASE 1 pc.

(2) SPRING 1 pc.

(3) INNER POLE 1 pc.

(4) OUTER POLE 1 pc.

(5) DRESS FORM 1 pc.

(6) TOPPER 1 pc.



(1)

(2)











(6)




Step 1

Place BASE (Item 1) firmly on the ground.



Step 2

Insert SPRING (Item 2) through bottom end of INNER POLE (Item 3)



Step 3


Insert INNER POLE (Item 3) into the BASE (Item 1) all the way to the bottom until foot pedal flip up.






Step 4

Use a screw-driver or any similar tool to tighten by inserting into hole and turning clockwise to tighten the INNER POLE into the BASE.



Step 5

Slide OUTER POLE (Item 4) through INNER POLE (Item 3) while stepping on the pedal. Stepping on the pedal makes the "cut" at the top of INNER POLE align.



The top of INNER POLE should align as shown above while stepping on the foot pedal.



Step 6

Put the DRESS FORM over OUTER POLE.



Step 7

Twist TOPPER on the DRESS FORM.



Congratulation! Installation Complete!

Tips

- · You can easily adjust the height or rotate the dress form by:
 - 1. Stepping on the pedal
 - 2. Lifting the dress form / Rotate the dress form
 - 3. Let go of pedal

(If you do not follow these tips, you might damage the interior structure of the dress form.)