



701C PGM Children Display Form

Assembling Guide

You should have the following:

- (1) BASE**
- (2) POLE**
- (3) CHILDREN'S DISPLAY FORM**






Step 1

Plant *BASE* firmly on the ground.

Step 2

Insert *POLE* into the *BASE*.

* Make sure to twist the screw tightly after *POLE* is inserted into the *BASE* completely.



* Make sure to have *POLE* standing on the end of the foot pedal.

Step 3

Slide the *CHILDREN's DISPLAY FORM* over the *POLE*.

*When you are sliding *CHILDREN's DISPLAY FORM* over the *POLE*, make sure you are stepping down on the foot pedal with the top of *POLE* closed (see accompanied picture).



Now, you have your *CHILDREN's DISPLAY FORM* Combination completely installed.

Step 4

You may also slide *CHILDREN's DISPLAY FORM* over the *POLE* from the leg.

*When you are sliding *CHILDREN's DISPLAY FORM* over the *POLE*, make sure you are stepping down on the foot pedal with the top of *POLE* closed (see accompanied picture).



Now, you have your *CHILDREN's DISPLAY FORM* Combination completely installed.